


MT100VA.LZ series metal tube rotameter wiring connection diagram

(Vertical install and horizontal install same)



- 1、 Take off the green junction box
- 2、 The red line is connected with the positive pole, the black line is connected with the negative pole.
- 3、 Install back the green connection box